flap

Sharing. Intelligence. Greatness.

TECHNICAL SPECS

- Android™ 4.0, Ice Cream Sandwich
- Bluetooth® Wireless Connectivity Capable
- Wi-Fi® 802.11 a/b/g/n
- NFC Capable
- Dimensions: 5.4" x 2.8" x 0.3"
- Display: 4.8" HD Super AMOLED™ (1280x720)
- Weight: 4.7 oz
- Standard Battery: 2100 mAh
- 6-Axis Accelerometer
- Gyroscope
- Proximity Sensor
- Digital Compass
- Barometer

MEMORY

- 16GB and 32GB memory options
- microSD™ memory card support (optional accessory) – up to 64GB

Samsung GALAXY S III

back

ORDER

Genuine Samsung Accessories
samsung.com/us/mobile/cell-phones-accessories
1.800.SAMSUNG

U.S. Cellular

– For Internal Use Only –

© 2012 Samsung Telecommunications America, LLC. Samsung, Galaxy S and AMOLED are all trademarks of Samsung Electronics Co., Ltd. Google, Google Mobile, Google Play and other marks are trademarks of Google Inc. Appearance of device may vary. Screen images simulated. Other company names, product names and marks mentioned herein are the property of their respective owners and may be trademarks or registered trademarks. Printed in U.S.A.

SAMSUNG

Samsung GALAXY S III

front

TAKING PICTURES

1. Swipe the **Camera** icon when the screen is locked, touch the **Camera** icon on the Home screen, or touch **Apps**, then **Camera** to activate.

2. Using the display as a viewfinder, point the camera lens at your subject.

3. When the image you wish to capture appears in the display, press the **Camera** button or, if S Voice is activated, just say “cheese” to take a picture.

4. After taking the picture, you can touch the **thumbnail image** to view, share or upload your picture.

CAPTURING VIDEOS

1. Swipe the **Camera** icon when the screen is locked, touch the **Camera** icon on the Home screen, or touch **Apps**, then **Camera** to activate.

2. Slide the **Camera** mode button from picture to video.

3. Using the display as a viewfinder, point the camcorder lens at your subject.

4. When the image that you wish to capture appears in the display, press the **Record** button to start recording. Press the **Record** button to stop recording.

5. After recording your video, you can press the **thumbnail image** to view, edit and share your video.

ACCESSING GOOGLE PLAY™ STORE AND DOWNLOADING A NEW APP

1. From the Home screen, touch the **Play Store** icon or touch **Apps**, then the **Play Store** icon.

2. If not already logged in to your Google™ account, touch **Existing**. Touch **New** and follow the on-screen prompts if you need to create an account.

3. Touch **Sign in** and enter your Google account information.

4. Touch **Accept** to agree to Play Store’s terms of service.

5. Browse through the categories, find an application you’re interested in, and touch the name.

6. Touch **Download** if the app is free, then **Accept & download**. If it’s a paid app, follow the on-screen prompts in order to purchase and download the app.

PAIRING BLUETOOTH® DEVICES

1. Verify Bluetooth® is active.

2. Place the other Bluetooth device in discoverable mode. (See the device user manual for more information.)

3. Touch **Scan for devices**. Your device displays a list of discovered in-range Bluetooth devices.

4. Touch a device from the list to initiate pairing.

5. Enter the passkey or PIN code, if needed, and touch **OK**.

6. The external device must accept the connection then enter your device’s PIN code.

7. Once successfully paired to a device, the Bluetooth icon displays in the Status area.

Tips & Tricks

SHARE CONTENT ON YOUR TV AND STEREO USING ALLSHARE® PLAY

AllShare® Play is perfect for sharing any of your favorite songs and user-generated content like vacation videos and family reunion photos. To get started with AllShare Play, you need a Samsung account. If you don’t have one, visit allshareplay.com to sign up.

ENABLE MOTION GESTURES

Customize how you interact with your Samsung Galaxy S® III and enable the motion gestures you want to use. To enable hand gestures and learn how to use them, touch **Settings**, then **Motion**. Touch the name of any gesture to view a tutorial. To enable eye-tracking features, touch **Settings**, **Display**, then **Smart Stay**.

MAKE A QUICK CALL FROM A TEXT MESSAGE

Reading a message from a friend, but want to respond with a call? Enable the **Pick Up to Call** gesture so you can just lift the phone to your ear while in the message screen, call log or contact details to dial the contact displayed on the screen. To enable the **Pick Up to Call** gesture, touch **Settings**, then **Motion**, and slide the bar to green on **Place to ear to make a call**.

MUTE AN INCOMING CALL

When the **Turn Over to Mute** gesture is enabled in your gesture settings, you can simply turn the phone over to mute the ringer of an incoming call, alarm or alert tone.

MULTITASK WITH VIDEO PICTURE-IN-PICTURE

When you need to check your email, send a text or surf the web while watching a video, there’s no need to pause the action anymore. Just touch the **picture-in-picture** icon within the media player and you’ll be able to move the screen around and multitask while you watch. Picture-in-picture works with content that plays in the native video player only.

SHINE A LIGHT

You’ll always have a flashlight handy thanks to the **Assistive Light** widget on your Galaxy S III. This widget turns your camera’s flash into a flashlight whenever you need one. To add the Assistive Light widget to your Home screen, touch **Apps**, select the **Widgets** tab, then touch **Assistive Light**.

Samsung GALAXY S III